



i Assembly instructions

The 'zoom' flag range we supply is designed to give you a choice of flexible pole sizes covering small, medium, large and extra large, and accommodate three different flag shapes. These specific instructions are for the 2.8m zoom event flag and other size configurations will vary, but **all flags** can be assembled the same way:

- 1** Remove the poles from the carry bag and slot them together, the amount of poles will differ according to which size of flag you have. The way they fit together should be thicker at the bottom going thinner towards the top pole which will ultimately bend to the shape of your chosen flag when secured. The bottom pole should have the tie off clasp for securing the flag.
- 2** Take the flag and thread the pole through the sleeve all the way to the top. There may be some resistance but this is normal.
- 3** Your flag should be secured with a cord and eyelet or bungee cord, which can be pulled to tighten or loosen the flag as necessary.
- 4** Your flag pole will then be secured to your chosen base.
- 5** Never fold or roll your flags and store in the bag whilst wet, always put it out to dry first.



For a range of useful resources, advice and guidance on printing, garments and signage check out the Print Solutions online resources hub: www.myprintsolutions.co.uk

PRINTING

GARMENTS

SIGNAGE